

MINI MAX II

Pocket reader



Customer benefits:

- Reading of FDX-B Transponder
- Operation according to ISO Standard 11784 / 11785 (reads FDX-B tags)
- Resistant to interference, providing a high quality signal
- Uses safe, reliable, low frequency radio waves
- Reads through most non-conductive materials
- 32 characters LCD (2 x 16)
- Beeper
- Runs on 1 pc. 9 Volts Alkaline battery
- Auto-power-off function after 90 seconds of no use

Product description:

In accordance with ISO Standard 11785, the MINI MAX II reads the ISO tags FDX-B and is CE approved. Its white housing and sophisticated design makes the MINI MAX II a smart pocket reader. Thanks to its lightness the MINI MAX II pocket reader can be used at any place and time. An acoustic signal informs the user that a tag has been read, the code is then displayed on the LCD screen. The MINI MAX II reads more than 3000 identification codes before a change of battery is required. After 90 seconds of non-use, the reader automatically shuts down (auto-power-off function) for allowing the battery's life to be prolonged.

TECHNICAL DATA:

Dimensions:	16.4 x 4.9 x 2.5 cm
Weight:	144 g
Operating temperature:	0°C to +50°C
Storage temperature:	-25°C to +60°C
Power supply:	9 volts Alkaline battery (Type AM6 6LR61) Battery lasts for approx. 3000 readings
Working frequency:	134,2 kHz
Reading distance:	Up to 10 cm
Housing:	White ABS
Approved by:	CE / FCC

Subject to change without notice



DATAMARS' innovative RFID-based solutions are the result of 20 years of industry experience that have enabled the company to establish itself as the global market leader in the companion animal identification market. Having driven the development of ISO standards for companion animal identification, DATAMARS works with pharmaceutical companies, shelters, kennel clubs and charitable organizations to deploy its unique pet identification and reunification solution to improve the lives of companion animals around the world.

DATAMARS

Americas Headquarters:
8433 South Av. Bldg., 4-2
Youngstown, OH 44514 USA
Phone: +1 330 758 1240
Fax: +1 330 758 3805

Corporate Headquarters:
Via ai Prati
6930 Bedano-Lugano
Switzerland
Phone: +41 91 935 73 80
Fax: +41 91 945 03 30
animal-id@datamars.com
www.datamars.com

Asia Headquarters:
Northern Region Industrial Estate
179/1 Moo 4, T. Ban Klang, A. Muang
Lamphun, Thailand 51000
Phone: +66 53 582 021
Fax: +66 53 582 680